



Weatherseal Kit Installation

Sealeze Brush Weatherseals install in 5 easy steps:

1. Measure the door (bottom, jambs and header).
2. Cut the brush and holder to length.
3. Pry open the ends of the holder with a screwdriver.
4. Insert the brush into the holder and peen both ends of the holder with a hammer to lock the brush in place.
5. Mount the seal by holding the aluminum flange to the jambs or door bottom while aligning brush to the proper fit.
Then secure with self-drilling screws provided. Slotted holes allow for easy final adjustment for the perfect fit.

Tips

- Cut Brush with diagonal cutting pliers, shears or bolt cutters. Cutting action must pinch ends closed to seal in filaments.
- Cut Holder with hack saw, power saw (with metal cutting blade), or angle iron shear.
- Mount Jamb Seals for either entrance or overhead doors by installing header first, then measure for jamb seal. Mount so brush is flexed slightly against the door to ensure complete seal and to compensate for wind deflection.
- Mount Sweep so brush just touches floor or top of threshold.
- Mount Astragal Seals so brushes just touch in the center of gap between doors.
- Splice the Brush when door dimensions exceed stocked weatherseal lengths. "Splice" 2 or more pieces together by staggering the brush and holder joints.



Sealeze, A Unit of Jason Incorporated
8000 Whitepine Road
Richmond, VA 23237