

Weatherseal Kit Installation

Installation Guide for Adjustable Door Bottom Seals

Instructions:

1. Measure the door bottom
2. Cut the holder to length
3. Pry open the end with a screw driver
4. Insert one end of the neoprene strip into the back channel
5. Fold the neoprene so that the other end can be inserted into the front channel
6. Check to be sure that the raised ridges are on the outside surface
7. Carefully guide the edges through the channels until the end of the neoprene strip is flush with the end of the holder
8. Trim excess neoprene with a utility knife
9. Mount the seal so that the neoprene just touches the floor or the top of the threshold

