

Weatherseal Kit Installation

For Entry Doors and Garage Doors

Brush Weatherseals install in 5 easy steps:

1. Measure the door and order the correct door sweep kit.
2. If your door is wider than stock brush weatherseal, cut the brush and holder to length and splice together.
3. Pry open the ends of the holder with a screwdriver.
4. Insert the brush into the holder and peen both ends of the holder with a hammer to lock the brush in place.
5. Mount the seal by holding the aluminum flange to the jambs or door bottom while aligning brush to the proper fit. Then secure with self-drilling screws provided. Slotted holes allow for easy final adjustment for the perfect fit.

Tips

- Cut Brush with diagonal cutting pliers, shears or bolt cutters. Cutting action must pinch ends closed to seal in filaments.
- Cut Holder with hack saw, power saw (with metal cutting blade), or angle iron shear.
- Mount Sweep so brush just touches floor or top of threshold.
- Splice the Brush when door dimensions exceed stocked weatherseal lengths. "Splice" 2 or more pieces together by staggering the brush and holder joints.

